

# History of KODAK Cameras



## KODAK CAMERAS

CAMERA NAME	ON THE MARKET		FILM SIZE	ORIGINAL LIST PRICE
	FROM	TO		
No. 1A AUTOGRAPHIC KODAK 1917 Model Camera	1917	1924	116	\$21.00
No. 3 AUTOGRAPHIC KODAK Camera	1914	1926	118	41.50
No. 3A AUTOGRAPHIC KODAK Camera	1914	1934	122	50.50
No. 1 AUTOGRAPHIC KODAK Junior Camera	1914	1927	120	23.00
No. 1A AUTOGRAPHIC KODAK Junior Camera	1914	1927	116	24.00
No. 2C AUTOGRAPHIC KODAK Junior Camera	1916	1927	130	27.00
No. 3A AUTOGRAPHIC KODAK Junior Camera	1918	1927	122	29.00
No. 1 AUTOGRAPHIC KODAK Special Camera (Bakelite side panels)	1915	1920	120	56.00
No. 1 AUTOGRAPHIC KODAK Special Camera (Model B) (Back overlaps sides) Focus by thumb-turned gear. (Only produced for a few months)	1921	1921	120	79.00
No. 1 AUTOGRAPHIC KODAK Special Camera (Model B) (knurled screw focusing)	1922	1926	120	74.00
No. 1A AUTOGRAPHIC KODAK Special Camera	1914	1916	116	59.50
No. 1A AUTOGRAPHIC KODAK Special Camera (w/coupled rangefinder and Bakelite side panels)	1917	1923	116	91.00
No. 1A AUTOGRAPHIC KODAK Special Camera w/coupled rangefinder, Model B (Back overlaps sides)	1923	1926	116	60.00
No. 2C AUTOGRAPHIC KODAK Special Camera w/coupled rangefinder	1923	1928	130	65.00
No. 3 AUTOGRAPHIC KODAK Special Camera	1914	1926	118	86.00
No. 3A AUTOGRAPHIC KODAK Special Camera	1914	1916	122	74.00
No. 3A AUTOGRAPHIC KODAK Special Camera (w/coupled rangefinder)	1916	1934	122	109.50
Boy Scout KODAK Camera (V.P. Model B)	1929	1934	127	6.00
Baby BROWNIE Camera	1934	1941	127	1.00
Export Version BROWNIE 127 Camera	1936	1939	127	—
Baby BROWNIE Special Camera	1939	1954	127	1.25
Export Version BROWNIE Special 127 Camera	1939	--	127	—
No. 2 Beau BROWNIE Camera (5 colors)	1930	1933	120	4.25
No. 2A Beau BROWNIE Camera (5 colors)	1930	1933	116	5.25
Boy Scout BROWNIE Camera	1932	1932	120	2.00
The BROWNIE Camera	1900	1901	117	1.00
No. 0 BROWNIE Camera	1914	1935	127	1.25
No. 1 BROWNIE Camera	1901	1916	117	1.00
No. 2 BROWNIE Camera	1901	1924	120	2.00
No. 2 BROWNIE Camera (Aluminum, Model F)	1924	1933	120	2.75
No. 2 BROWNIE Camera (5 colors)	1929	1933	120	2.50

CAMERA NAME	ON THE MARKET		FILM SIZE	ORIGINAL LIST PRICE
	FROM	TO		
No. 2A BROWNIE Camera	1907	1924	116	\$3.00
No. 2A BROWNIE Camera (Aluminum, Model C)	1924	1933	116	3.75
No. 2A BROWNIE Camera (5 colors)	1929	1933	116	4.00
No. 2C BROWNIE Camera	1917	1934	130	4.00
No. 3 BROWNIE Camera	1908	1934	124	4.00
BROWNIE 127 Camera (Imported from KLtd.)	1953	1954	127	4.75
BROWNIE Auto 27 Camera Outfit	1963	1965	127	34.50
BROWNIE BULLET Camera (Premium version of the BROWNIE Holiday Camera)	1957	1964	127	*
BROWNIE BULLET II Camera	1961	1968	127	4.75
BROWNIE BULLS-EYE Camera (Black model)	1954	1958	620	13.00
BROWNIE BULLS-EYE Camera (Gold model)	1957	1960	620	15.00
BROWNIE FIESTA Camera (Two-tone gray and silver)	1962	1965	127	6.00
BROWNIE FIESTA Camera (Two-tone dark and light blue)	1965	1966	127	6.00
BROWNIE FIESTA R4 Camera	1966	1970	127	9.00
BROWNIE Flash 20 Camera	1959	1962	620	14.00
BROWNIE Flash Six-20 Camera	1946	1955	620	6.00
BROWNIE FLASHMITE 20 Camera	1960	1965	620	15.00
BROWNIE HAWKEYE Camera	1949	1951	620	5.50
BROWNIE HAWKEYE, Flash Model Camera	1950	1961	620	7.00
BROWNIE Holiday Flash Camera	1953	1962	127	5.00
BROWNIE Reflex Camera	1940	1941	127	5.25
BROWNIE Reflex, Synchro Model Camera	1941	1952	127	6.00
BROWNIE Reflex 20 Camera	1959	1966	620	17.00
BROWNIE Six-20 Model D Camera	1953	1954	620	10.00
BROWNIE Special No. 2 Camera	1933	1934	120	2.25
BROWNIE STARFLASH Camera (black)	1957	1965	127	8.50
(red)	1958	1960	127	8.50
(white)	1958	1962	127	8.50
(blue)	1958	1962	127	8.50
BROWNIE STARFLASH Camera with Coca Cola Decal	1959	1961	127	*
BROWNIE STARFLEX Camera	1957	1964	127	10.00
BROWNIE STARLET Camera (Imported from KLtd.)	1956	1956	127	4.00
BROWNIE STARLET Camera	1957	1962	127	6.00
BROWNIE STARMATIC Camera	1959	1961	127	34.50
BROWNIE STARMATIC II Camera	1961	1963	127	34.50
BROWNIE STARMETER Camera	1960	1965	127	20.00
BROWNIE STARMITE Camera	1960	1963	127	10.50
BROWNIE STARMITE II Camera	1962	1967	127	12.00
BROWNIE Super 27 Camera	1961	1965	127	19.00
BROWNIE Target Six-16 Camera	1946	1951	616	4.00
BROWNIE Target Six-20 Camera	1946	1952	620	3.50
BROWNIE Twin 20 Camera	1959	1964	620	11.00

CAMERA NAME	ON THE MARKET		FILM SIZE	ORIGINAL LIST PRICE
	FROM	TO		
No. 2 Folding AUTOGRAPHIC BROWNIE Camera (Changed from square to round ends in 1917)	1915	1926	120	\$12.00
No. 2A Folding AUTOGRAPHIC BROWNIE Camera (Changed from square to round ends in 1917)	1915	1926	116	13.00
No. 2C Folding AUTOGRAPHIC BROWNIE Camera (Changed from square to round ends in 1917)	1916	1926	130	16.00
No. 3A Folding AUTOGRAPHIC BROWNIE Camera	1916	1926	122	18.00
No. 2 Folding Pocket BROWNIE Camera (Model B)	1907	1915	120	5.00
No. 2A Folding Pocket BROWNIE Camera	1910	1915	116	7.00
No. 3 Folding Pocket BROWNIE Camera	1905	1909	124	11.00
Metal Lens Board	1910	1915		11.00
No. 3A Folding BROWNIE Camera	1909	1915	122	12.00
New York World's Fair Baby BROWNIE Camera	1939	1940	127	1.25
Six-16 BROWNIE Camera	1933	1941	616	3.50
Six-16 BROWNIE Junior Camera	1934	1942	616	2.75
Six-16 BROWNIE Special Camera	1938	1942	616	4.50
Six-20 Boy Scout BROWNIE Camera	1933	1934	620	2.25
Six-20 BROWNIE Camera	1933	1941	620	2.50
Six-20 BROWNIE Junior Camera	1934	1942	620	2.25
Six-20 BROWNIE Special Camera	1938	1942	620	4.00
Six-20 BULLS-EYE BROWNIE Camera	1938	1941	620	3.00
Six-20 Flash BROWNIE Camera	1940	1946	620	4.25
No. 2 Stereo BROWNIE Camera	1905	1910	125	12.00
Target BROWNIE Six-16 Camera	1941	1946	616	3.00
Target BROWNIE Six-20 Camera	1941	1946	620	2.75
No. 2 BULLET Camera	1895	1896	101	8.00
No. 2 BULLET Improved Camera	1896	1900	101 or single plate holder	10.00
No. 2 BULLET KODAK Camera (new model with brilliant finder)	1900	1902	101 or double plate holder	10.00
No. 4 BULLET Camera	1896	1900	103 or single plate holder	15.00
No. 2 BULLET Special Camera	1898	1904	101 or double plate holder	18.00
No. 4 BULLET Special KODAK Camera	1898	1900	cartridge roll holder or double plate holder	25.00
No. 4 BULLET Special KODAK Camera, Model C	1901	1904	103 or double plate holder	22.50
No. 2 BULLS-EYE KODAK Camera and Models 1896, 1897, 1898, C and D	1895	1913	101	8.00
No. 3 BULLS-EYE KODAK Camera, Model A	1908	1913	124	8.00
No. 4 BULLS-EYE KODAK Camera, Models 1896, 1897, 1898, C and D	1896	1904	103	12.00
No. 2 BULLS-EYE Special KODAK Camera, Models 1898, 1899, and C	1898	1904	101	15.00
No. 4 BULLS-EYE Special KODAK Camera, Models 1898 and C (Two different cameras in 1898)	1898	1904	103	20.00

CAMERA NAME	ON THE MARKET		FILM SIZE	ORIGINAL LIST PRICE
	FROM	TO		
Camp Fire Girls' KODAK Camera (V.P. Model B)	1931	1934	127	\$6.00
No. 3 Cartridge KODAK Camera (metal front slide block focus)	1900	1900	119 and glass plate adapter	51.00
No. 3 Cartridge KODAK Camera (metal front slide block focus) (Improved metal front, bed extension, longer bellow and rack pinion focus 1901)	1901	1907	119 and glass plate adapter	72.00
No. 4 Cartridge KODAK Camera (wood front)	1897	1900	104 and glass plate adapter	66.00
No. 4 Cartridge KODAK Camera (wood front) (Improved metal front mount, bed extensions, and longer bellows)	1900	1907	104 and glass plate adapter	82.50
No. 5 Cartridge KODAK Camera (wood front)	1898	1900	115 and glass plate adapter	85.50
No. 5 Cartridge KODAK Camera (wood front) (Improved metal front mount and bed, bed extension, and longer bellows)	1900	1907	115 and glass plate adapter	105.00
Century of Progress World's Fair Souvenir 1833-1933 Camera	1933	1933	120	4.00
"A" Daylight KODAK Camera	1891	1895	daylight loading	8.50
"B" Daylight KODAK Camera	1891	1895	daylight loading	15.00
"C" Daylight KODAK Camera	1891	1895	daylight loading or glass plate adapter	25.00
EASTMAN BULLET Camera	1936	1942	127	2.75
EASTMAN Pinhole Camera	1930	--	sheet film	.15
No. 3 EASTMAN Plate Camera Series C	1901	1904	plates	74.50
No. 3 EASTMAN Plate Camera Series D (Identical to Series C but with 3 1/2-inch longer bellows)	1901	1904	plates	79.50
No. 4 EASTMAN Plate Camera Series C	1901	1903	plates	76.50
No. 4 EASTMAN Plate Camera Series D (Identical to Series C but with 3 1/2-inch longer bellows)	1901	1903	plates	81.50
No. 5 EASTMAN Plate Camera Series D	1902	1903	plates	97.00
No. 2 Eureka Camera	1898	1901	106 with roll holder	4.00
No. 4 Eureka Camera	1899	1901	109 with roll holder	6.00
No. 2 Eureka Junior Camera	1898	1901	plates	2.50
No. 1 Falcon KODAK Camera	1897	1898	special	6.00 (loaded)
No. 2 Falcon KODAK Camera	1897	1899	101	5.00
The Anniversary Camera, or EASTMAN Anniversary Camera	1930	1930		6.00 (loaded)
FISHER-PRICE Camera (made by Kodak)	1984		110	25.00
No. 2 FLEXO KODAK Camera (Replaced No. 2 Falcon)	1899	1913	101	5.00
No. 2 Folding BULLS-EYE Camera	1899	1901	101	10.00
No. 4 Folding KODAK Camera	1890	1892	EASTMAN Walker roll holder	50.00
No. 4 Folding KODAK Camera (Improved camera)	1893	1897	EASTMAN Walker roll holder	50.00
No. 4A Folding KODAK Camera (wood front)	1906	1907	126	103.00
No. 4A Folding KODAK Camera, Model B (Improved metal front)	1908	1915	126	109.50

CAMERA NAME	ON THE MARKET		FILM SIZE	ORIGINAL LIST PRICE
	FROM	TO		
No. 5 Folding KODAK Camera	1890	1892	EASTMAN Walker roll holder	\$60.00
No. 5 Folding KODAK Camera (Improved camera)	1893	1897	EASTMAN Walker roll holder	75.00
No. 6 Folding KODAK Camera	1893	1895	EASTMAN Walker roll holder	100.00
No. 0 Folding Pocket Camera (Model A)	1902	1902	121	6.00
No. 0 Folding Pocket Camera (Model B) (w/ctr pins for spools)	1902	1906	121	6.00
Folding Pocket KODAK Camera (collapsing front, brass fittings)	1897	1898	105	10.00
Folding Pocket KODAK Camera (nickel fittings)	1898	1899	105	10.00
No. 1 Folding Pocket KODAK Camera (Model B) (formerly Folding Pocket KODAK Camera w/nickel fittings)	1899	1905	105	10.00
No. 1 Folding Pocket KODAK Camera (Model C) (w/folding front)	1905	1907	105	10.00
No. 1 Folding Pocket KODAK Camera (Model D) (improved shutter 1/08)	1907	1910	105	10.00
No. 1 Folding Pocket KODAK Camera (Model E)	1910	1915	105	10.00
No. 1A Folding Pocket KODAK Camera (collapsing front)	1899	1905	116	12.00
No. 1A Folding Pocket KODAK Camera Model B (folding front)	1905	1906	116	12.00
No. 1A Folding Pocket KODAK Camera Model C (wood lens mount)	1907	1909	116	12.00
No. 1A Folding Pocket KODAK Camera Model D (metal lens mount)	1909	1915	116	12.00
No. 2 Folding Pocket KODAK Camera	1899	1910	101	15.00
No. 3 Folding Pocket KODAK Camera Models A, AB, AB-EX, ABX, B, B-2, B-3, B-4, C, C-2, C-3, C-4, C-5, D, E, E-2, E-3, E-4, F, G, and H	1900	1915	118	68.00
No. 3 Folding Pocket KODAK Deluxe Camera (Persian Morocco Covering silk bellows)	1901	1903	118	75.00
No. 3A Folding Pocket KODAK Camera Models B, B-2, B-3, B-4, B-5, C, and G	1903	1915	122	78.00
No. 4 Folding Pocket KODAK Camera	1907	1915	123	83.00
No. 1A Folding Pocket KODAK-RR Type Camera (formerly listed as No. 1A Folding Pocket KODAK Special)	1912	1915	116	59.00
No. 1A Folding Pocket KODAK Special Camera	1908	1912	116	59.00
No. 1A Gift KODAK Camera (packed in cedar box) (10,000 manufactured)	1930	1931	116	15.00
Girl Scout KODAK Camera (V.P. Model B)	1929	1934	127	6.00
No. 4 Glass Plate Folding KODAK Camera	1892	1897	plates	55.00
No. 5 Glass Plate Folding KODAK Camera	1892	1897	plates	65.00
No. 6 Glass Plate Folding KODAK Camera	1894	1895	plates	84.00
JIFFY KODAK Six-16 Camera	1933	1937	616	7.50
JIFFY KODAK Six-16 Series II Camera	1937	1942	616	10.00
JIFFY KODAK Six-20 Camera	1933	1937	620	6.75
JIFFY KODAK Six-20 Series II Camera	1937	1948	620	9.00
JIFFY KODAK V. P. Camera	1935	1942	127	5.00
No. 3 Junior Glass Plate KODAK Camera	1892	1897	plates	40.00
No. 4 Junior Glass Plate KODAK Camera	1892	1897	plates	50.00

CAMERA NAME	ON THE MARKET		FILM SIZE	ORIGINAL LIST PRICE
	FROM	TO		
The KODAK Camera (highest Serial No. known 5192)	1888	1889	factory loaded	\$25.00
No. 1 KODAK Camera (highest Serial No. known 15,559)	1889	1895	factory loaded	25.00
No. 2 KODAK Camera	1889	1897	factory loaded	32.50
No. 3 KODAK Camera	1889	1897	factory loaded	40.00
No. 4 KODAK Camera	1889	1897	factory loaded	50.00
KODAK 35 Camera	1938	1948	135	40.00
KODAK 35, f/3.5, with Rangefinder Camera	1940	1951	135	48.00
KODAK ADVANTIX C300 Auto Camera	1998		240	59.00
KODAK ADVANTIX C400 Auto Focus Camera	1998		240	159.00
KODAK ADVANTIX C650 Zoom Camera	1998		240	69.00
KODAK ADVANTIX C700 Zoom Camera	1998		240	189.00
KODAK ADVANTIX F300 Auto Camera	1998		240	49.00
KODAK ADVANTIX F600 Zoom Camera	1999		240	129.00
KODAK ADVANTIX T500 Auto Focus Camera	1998		240	139.00
KODAK ADVANTIX T550 Auto Focus Camera	1998		240	149.00
KODAK ADVANTIX 1600 Auto Camera	1997		240	79.95
KODAK ADVANTIX 2000 Auto Camera	1996		240	99.95
KODAK ADVANTIX 2100 Auto Camera	1996		240	99.95
KODAK ADVANTIX 3200AF Camera	1996		240	119.95
KODAK ADVANTIX 3600ix Camera	1996		240	189.95
KODAK ADVANTIX 3700ix Camera	1996		240	194.95
KODAK ADVANTIX 4100ix Zoom Camera	1996		240	229.95
KODAK ADVANTIX 4700ix Zoom Camera	1997		240	309.95
KODAK ADVANTIX 5600MRX Text-Date Camera	1996	1997	240	577.20
KODAK ADVANTIX 5800MRX Zoom Camera	1996	1998	240	429.00†
KODAK FUN SAVER ADVANTIX One-Time-Use Flash Camera	1996		240	19.95
KODAK Automatic 35 Camera	1959	1964	135	84.50
KODAK Automatic 35B Camera	1961	1962	135	89.50
KODAK Automatic 35F Camera	1962	1966	135	99.50
KODAK Automatic 35R4 Camera	1965	1969	135	94.50
KODAK BANTAM Camera (Rigid finder) (replacement folding optical finder available from dealer 2/38)	1935	1937	828	9.75
KODAK BANTAM Camera (metal frame finder) (replacement folding optical finder available from dealer 2/38)	1935	1938	828	5.75
KODAK BANTAM Camera (folding optical finder)	1938	1947	828	8.50
KODAK BANTAM f/4.5 Camera	1938	1948	828	27.50
KODAK BANTAM f/5.6 Camera	1938	1941	828	16.50
KODAK BANTAM f/8 Camera	1938	1942	828	4.75
KODAK BANTAM Special Camera	1936	1948	828	110.00
KODAK BANTAM RF Camera (Sold as the KODAK Town and Country Camera outfit consisting of camera, case, and flash holder)	1953	1957	828	78.50
KODAK BANTAM RF Camera (camera only)	1954	1957	828	62.75
KODAK BREEZE Camera	1989	1990	135	59.95
KODAK Flash BANTAM Camera	1947	1953	828	58.00
KODAK CAMEO Auto Focus Camera	1994	1996	135	129.95
KODAK CAMEO Focus Free Camera	1993		135	52.95
KODAK CAMEO Motor 110 Camera	1993		110	34.95
KODAK CAMEO Motor EX Camera	1995		135	79.95

CAMERA NAME	ON THE MARKET		FILM SIZE	ORIGINAL LIST PRICE
	FROM	TO		
KODAK CAMEO Motordrive Camera	1995	1995	135	\$99.95
KODAK CAMEO Zoom Plus Camera	1993	1995	135	199.95
KODAK CHEVRON Camera	1953	1956	620	215.00
KODAK Coquette Camera (KODAK Petite Camera w/matching lipstick holder and compact)	1930	1932	127	12.50
KODAK DC25 Digital Camera	1996			499.00
KODAK DIGITAL SCIENCE™ DC20 Camera	1996			299.00
KODAK DIGITAL SCIENCE DC40 Camera	1996	1996		599.00
KODAK DIGITAL SCIENCE DC50 Zoom Camera	1996			899.00
KODAK Disc 2000 Camera (export)	1982	1984	HR-disc	52.00
KODAK Disc 3000 Camera*	1983	1984	HR-disc	57.00
KODAK Disc 3500 Camera (export)	1983	1985	HR-disc	57.00
KODAK Disc 4000 Camera	1982	1984	HR-disc	68.00
KODAK Disc 6000 Camera	1982	1984	HR-disc	90.00
KODAK Disc 8000 Camera‡	1982	1984	HR-disc	143.00
KODAK Disc 3100 Camera	1984	1987	VR disc	48.00
HAWKEYE Disc 7000 Camera	1985	1985	VR disc	*
KODAK Disc 4100 Camera	1984	1987	VR disc	66.00
KODAK Disc 6100 Camera	1984	1987	VR disc	87.00
KODAK Disc 3600 Camera	1986	1990	VR disc	45.00
KODAK CHALLENGER Disc Camera	1986	1990	VR disc	*
KODAK Tele Disc Camera	1985	1990	VR disc	58.00
KODAK MEDALIST I Disc Camera (special edition)	1986	1987	VR disc	66.00
KODAK MEDALIST II Disc Camera (special edition)	1986	1987	VR disc	87.00
KODAK MEDALIST Tele Disc Camera (special edition)	1986	1990	VR disc	58.00
KODAK Tele CHALLENGER Disc Camera	1985	1986	VR disc	*
KODAK DUAFLEX Camera	1947	1950	620	17.25
KODAK DUAFLEX II Camera ("B" changed to "L" for long exposure, 1/1953)	1950	1954	620	22.00
KODAK DUAFLEX III Camera	1954	1957	620	24.00
KODAK DUAFLEX IV Camera	1955	1960	620	24.50
KODAK DUEX Camera	1940	1942	620	5.75
KODAK Duo Six-20 Camera	1934	1937	620	57.50
KODAK Duo Six-20 Series II Camera	1937	1939	620	57.50
KODAK Duo Six-20 Series II Camera w/Rangefinder	1939	1940	620	85.00
KODAK EKTRA Camera	1941	1948	135	325.00
KODAK EKTRALITE 10 Camera	1978	1994	110	
KODAK Ensemble (KODAK Petite Camera in suede case with lipstick, compact, and mirror; three colors: beige, rose, green. Cosmetics by the House of Tre Jur)	1929	1933	127	15.00
KODAK EXPLORER 35 mm Camera	1989	1991	135	119.95

CAMERA NAME	ON THE MARKET		FILM SIZE	ORIGINAL LIST PRICE
	FROM	TO		
KODAK FLING Camera	1987	1989	110	\$6.95
KODAK FUN SAVER 35 Camera (formerly KODAK FLING 35 Camera)	1988		135	8.35
KODAK FUN SAVER 35 Camera / Trial Size	1995		135	6.65
KODAK FUN SAVER 35 Camera with Flash	1990		135	15.95
KODAK FUN SAVER 35 Camera with Flash / Trial Size	1995		135	11.35
KODAK FUN SAVER 35 Camera / with Flash Celebration Edition	1994	1994	135	11.35
KODAK FUN SAVER Panoramic 35 Camera (formerly KODAK STRETCH 35 Camera)	1989		135	12.95
KODAK FUN SAVER Portrait 35 Camera	1993	1995	135	19.95
KODAK FUN SAVER TeleFoto 35 Camera	1992	1995	135	14.95
KODAK FUN SAVER Pocket Daylight Camera	1995		135	10.95
KODAK FUN SAVER Pocket Flash Camera	1995		135	18.95
KODAK FUN SAVER Pocket Flash Camera / with OPEN ME FIRST Edition	1995	1995	135	18.95
KODAK FUN SAVER Party Pack (Each pack contains 3 KODAK FUN SAVER 35 Cameras with Flash)	1996	1996	135	29.95
KODAK FUN SAVER WEEKEND 35 Camera	1989		135	13.95
Wedding Party Pack (Each pack contains 5 KODAK FUN SAVER 35 Cameras with Flash)	1995	1996	135	61.05
KODAK FUNTIME 35 Camera	1992		135	*
KODAK FUNTIME 35 Camera with Flash	1992		135	*
HAWKEYE FLASHFUN Camera	1961	1967	127	*
HAWKEYE FLASHFUN II Camera	1965	1969	127	*
HAWKEYE INSTAMATIC @ Camera	1963	1967	126	*
HAWKEYE INSTAMATIC F Camera	1964	1968	126	*
HAWKEYE INSTAMATIC R4 Camera	1965	1971	126	*
HAWKEYE INSTAMATIC II Camera	1969	1975	126	*
HAWKEYE INSTAMATIC A-1 Camera	1969	1972	126	*
HAWKEYE INSTAMATIC X Camera	1971	1978	126	*
HAWKEYE Pocket INSTAMATIC Camera	1973	1979	110	*
HAWKEYE Pocket INSTAMATIC III Camera	1974	1979	110	*
HAWKEYE TELE-INSTAMATIC Camera	1976	1979	110	*
KODAK INSTAMATIC Cameras				
44	1969	1973	126	9.95
100	1963	1966	126	15.95
104	1965	1968	126	15.95
124	1968	1971	126	16.95
134	1968	1971	126	25.50
150 (Outfit)	1964	1966	126	29.50
154 (Outfit)	1965	1969	126	30.00
174	1968	1971	126	27.00
250 (Kodak AG)	1965	1967	126	33.75
300	1963	1966	126	44.50
304	1965	1969	126	44.50
314	1968	1971	126	38.00
324 (Kodak AG)	1966	1968	126	74.50
400	1963	1966	126	52.50
404	1965	1969	126	55.50
414	1968	1971	126	48.00
500 (Kodak AG)	1964	1966	126	94.50
700	1963	1966	126	109.50
704	1965	1969	126	104.50
714	1968	1970	126	119.50
800	1964	1966	126	129.50
804	1965	1970	126	124.50
814	1968	1970	126	139.50



CAMERA NAME	ON THE MARKET		FILM SIZE	ORIGINAL LIST PRICE
	FROM	TO		
KODAK INSTAMATIC S-10 Camera	1967	1970	126	\$27.50
KODAK INSTAMATIC S-20 Camera	1967	1971	126	58.50
KODAK INSTAMATIC X-15 Camera	1970	1976	126	21.00
KODAK INSTAMATIC X-15F Camera	1976	1988	126	19.50
KODAK INSTAMATIC X-25 Camera	1970	1974	126	31.00
KODAK INSTAMATIC X-30 Camera	1971	1974	126	38.00
KODAK INSTAMATIC X-35 Camera	1970	1976	126	48.00
KODAK INSTAMATIC X-35F Camera	1976	1981	126	53.50
KODAK INSTAMATIC X-45 Camera	1970	1974	126	58.00
KODAK INSTAMATIC X-90 Camera	1970	1973	126	144.50
KODAK INSTAMATIC Reflex f/2.8	1968	1974	126	199.00
KODAK INSTAMATIC Reflex f/1.9	1968	1974	126	249.00
KODAK INSTAMATIC Reflex (body only, black)	1968	1973	126	157.00
KODAK INSTAMATIC Reflex (body only, chrome)	1969	1974	126	162.00
KODAK Instant Cameras				
KODAK EK4 Instant Camera	1976	1978	PR10 (PR144)	53.50
KODAK EK6 Instant Camera	1976	1978	PR10 (PR144)	69.50
KODAK EK8 Instant Camera	1977	1979	PR10 (PR144)	not sold in U.S.
The HANDLE, KODAK Instant Camera (KODAK EK2 Instant Camera)	1977	1979	PR10 (PR144)	40.00
PLEASER KODAK Instant Camera	1977	1982	PR10 (PR144)	*
HAPPY TIMES KODAK Instant Camera (Coca Cola)	1978	1979	PR10 (PR144)	*
HANDLE 2 KODAK Instant Camera (EK22)	1979	1981	PR10 (PR144)	35.00
KODAK COLORBURST 100 Instant Camera	1978	1980	PR10 (PR144)	45.00
KODAK COLORBURST 200 Instant Camera	1978	1980	PR10 (PR144)	55.00
KODAK COLORBURST 300 Instant Camera	1978	1980	PR10 (PR144)	75.00
KODAK COLORBURST 50 Instant Camera	1979	1982	PR10 (PR144)	45.00
KODAK COLORBURST 250 Instant Camera	1979	1982	PR10 (PR144)	76.50
KODAK COLORBURST 350 Instant Camera	1981	1982	PR10 (PR144)	96.50
CHAMP KODAMATIC Instant Camera (named changed to the following:)	1982	1984	HS144	30.00
KODAK TRIMPRINT 920 Instant Camera	1984	1986	HS144	30.00
KODAMATIC 960 Instant Camera	1982	1986	HS144	78.00
KODAMATIC 970L Instant Camera	1982	1986	HS144	93.00
KODAMATIC 980L Instant Camera	1982	1986	HS144	115.00
KODAMATIC 940 Instant Camera (named changed to the following:)	1983	1984	HS144	45.00
KODAK TRIMPRINT 940 Instant Camera	1984	1986	HS144	45.00
PARTYTIME Instant Camera	1980	1982	PR144	*
PARTYFLASH Instant Camera	1981	1982	PR144	*
PARTYTIME II KODAMATIC Instant Camera	1982	1984	HS144	*
PARTYFLASH II KODAMATIC Instant Camera	1982	1986	HS144	*
PLEASER II KODAMATIC Instant Camera	1982	1985	HS144	*
PARTY STAR KODAMATIC Instant Camera (named changed to the following:)	1983	1984	HS144	*
PARTY STAR TRIMPRINT Instant Camera	1984	1986	HS144	*
PLEASER TRIMPRINT Instant Camera	1984	1986	HS144	*

CAMERA NAME	ON THE MARKET		FILM SIZE	ORIGINAL LIST PRICE
	FROM	TO		
No. 1 KODAK Junior Camera	1914	1914	120	\$7.50
No. 1A KODAK Junior Camera	1914	1914	116	11.00
No. 3 KODAK Junior Camera	1889	1897	factory loaded	40.00
No. 4 KODAK Junior Camera	1889	1897	factory loaded	50.00
KODAK Junior Six-16 Camera	1935	1937	616	12.00
KODAK Junior Six-16 Series II Camera	1937	1940	616	16.00
KODAK Junior or Six-16 Series III Camera	1938	1939	616	29.50
KODAK Junior Six-20 Camera	1935	1937	620	13.50
KODAK Junior Six-20 Series II Camera	1937	1940	620	14.00
KODAK Junior Six-20 Series III Camera	1938	1939	620	25.00
KODAK MEDALIST Camera (aluminum lens tube anodized black during World War II)	1941	1948	620	165.00
KODAK MEDALIST II Camera	1946	1953	620	215.00
MICKEY-MATIC Camera by Kodak	1988	1991	110	11.95
KODAK MONITOR Six-16 Camera	1939	1948	616	48.50
KODAK MONITOR Six-20 Camera	1939	1948	620	66.00
KODAK MOTORMATIC 35 Camera	1960	1962	135	109.50
KODAK MOTORMATIC 35F Camera	1962	1967	135	119.50
KODAK MOTORMATIC 35R4 Camera	1965	1969	135	114.50
KODAK Petite Camera (V.P. Model B in five colors: blue, gray, green, lavender, and old rose)	1929	1934	127	6.50
KODAK Pocket INSTAMATIC 10 Camera	1973	1976	110	23.00
KODAK Pocket INSTAMATIC 20 Camera	1972	1976	110	28.00
KODAK Pocket INSTAMATIC 30 Camera	1972	1976	110	48.00
KODAK Pocket INSTAMATIC 40 Camera	1972	1975	110	63.00
KODAK Pocket INSTAMATIC 50 Camera	1972	1976	110	108.00
KODAK Pocket INSTAMATIC 60 Camera	1972	1976	110	128.00
KODAK Pocket INSTAMATIC 60 Deluxe Camera Outfit	1973	1975	110	155.00
KODAK EKTRA 1 Camera	1978	1984	110	20.00
KODAK EKTRA 2 Camera	1978	1980	110	32.00
KODAK EKTRA 200 Camera (Kodak AG)	1980	1982	110	24.50
KODAK EKTRAMAX Camera	1978	1981	110	87.50
KODAK TELE-INSTAMATIC 608 Camera	1975	1979	110	35.95
KODAK TELE-INSTAMATIC 708 Camera	1976	1979	110	110.50
KODAK TELE-EKTRA 1 Camera	1978	1981	110	28.00
KODAK TELE-EKTRA 2 Camera	1978	1980	110	45.00
KODAK TELE-EKTRA 300 Camera	1980	1982	110	32.50
KODAK TELE-EKTRALITE 20 Camera	1979	1981	110	58.00
KODAK TELE-STYLELITE Camera	1980	1982	110	*
KODAK TELE-EKTRALITE 40 Camera	1979	1981	110	92.50
KODAK TELE-EKTRALITE 600 Camera	1980	1982	110	67.00
KODAK TRIMLITE INSTAMATIC 18 Camera	1975	1979	110	24.00
KODAK TRIMLITE INSTAMATIC 28 Camera	1975	1979	110	61.00
KODAK TRIMLITE INSTAMATIC 38 Camera	1975	1979	110	76.00
KODAK TRIMLITE INSTAMATIC 48 Camera	1975	1979	110	146.00

CAMERA NAME	ON THE MARKET		FILM SIZE	ORIGINAL LIST PRICE
	FROM	TO		
KODAK EKTRALITE 10 Camera	1978	1994	110	\$38.00
KODAK EKTRALITE 30 Camera	1979	1981	110	65.50
KODAK EKTRALITE 400 Camera (Kodak AG)	1981	1982	110	52.00
KODAK EKTRALITE 500 Camera	1980	1982	110	54.00
STYLELITE POCKET Camera	1979		110	*
KODAK PAZZAZZ Camera (rose and turquoise)	1988	1994	110	33.95
KODAK KB10 Camera	1997		135	
KODAK PONY 828 Camera	1949	1959	135	30.00
KODAK PONY 135 Camera	1950	1954	135	34.75
KODAK PONY 135 Model B Camera	1953	1955	135	36.75
KODAK PONY 135 Model C Camera	1955	1958	135	33.75
KODAK PONY II Camera	1957	1962	135	26.75
KODAK PONY IV Camera	1957	1961	135	40.00
KODAK PUPILLE Camera	1932	1935	127	75.00
KODAK RANCA Camera	1932	1934	127	16.50
KODAK RECOMAR 18 Camera	1932	1940	Film pack / Sheet pack	40.00
KODAK RECOMAR 33 Camera	1932	1940	Film pack / Sheet pack	48.00
KODAK Reflex Camera	1946	1949	620	100.00
KODAK Reflex 1A Camera (Factory-modified KODAK Reflex Camera)	1944			
KODAK Reflex II Camera	1948	1954	620	155.00
KODAK RETINA Camera (Black trim)	1934	1937	135	57.50
KODAK RETINA Camera (Chrome trim) (Name changed to: KODAK RETINA I Camera 11/1937)	1936	1939	135	57.50
KODAK RETINA I Camera	1939	1951	135	73.00
KODAK RETINA II Camera	1937	1950	135	198.00
KODAK RETINA IIa Camera	1951	1954	135	168.50
KODAK RETINA IIc Camera	1955	1958	135	135.00
KODAK RETINA IIF Camera	1964	1967	135	124.50
KODAK RETINA IIIc Camera	1954	1958	135	185.00
KODAK RETINA IIIC Camera (multi-frame adapter)	1958	1961	135	175.00
KODAK RETINA IIIs Camera	1959	1961	135	193.00
KODAK RETINA Automatic III Camera	1960	1965	135	129.50
KODAK RETINA Reflex Camera	1958	1959	135	215.00
KODAK RETINA Reflex S Camera	1959	1961	135	235.00
KODAK RETINA Reflex III Camera	1961	1965	135	248.50
KODAK RETINA Reflex IV Camera	1964	1968	135	277.00
KODAK RETINA S1 Camera	1967	1970	135	59.50
KODAK RETINETTE Camera	1952	1954	135	59.50
KODAK RETINETTE 1A Camera	1962	1963	135	45.00
KODAK RETINETTE 1A Camera (with hot shoe)	1963	1967	135	48.50

CAMERA NAME	ON THE MARKET		FILM SIZE	ORIGINAL LIST PRICE
	FROM	TO		
KODAK SENIOR Six-16 Camera	1937	1939	616	\$33.50
KODAK SENIOR Six-20 Camera	1937	1939	620	30.00
No. 3A KODAK Series II Camera	1936	1941	122	75.00
No. 1 KODAK Series III Camera	1926	1932	120	26.00
No. 1A KODAK Series III Camera	1924	1931	116	32.00
No. 2C KODAK Series III Camera	1924	1931	130	33.00
No. 3 KODAK Series III Camera	1926	1934	118	33.00
No. 3A KODAK Series III Camera	1941	1943	122	53.00
KODAK SIGNET 30 Camera	1957	1959	135	55.00
KODAK SIGNET 35 Camera	1951	1958	135	95.00
KODAK SIGNET 40 Camera	1956	1959	135	65.00
KODAK SIGNET 50 Camera	1957	1960	135	82.50
KODAK SIGNET 80 Camera	1958	1962	135	129.50
KODAK Special Six-16 Camera	1937	1939	616	48.50
KODAK Special Six-20 Camera	1937	1939	620	45.00
KODAK S Series Camera / Model S100EF	1988	1993	135	59.95
KODAK S Series Camera / Model S300MD / black	1988	1993	135	89.95
KODAK S Series Camera / Model S300MD / burgundy	1989	1993	135	89.95
KODAK S Series Camera / Model S400SL	1989	1991	135	119.95
KODAK S Series Camera / Model S500AF	1989	1991	135	189.95
KODAK S Series Camera / Model S900	1988	1993	135	229.95
KODAK S Series Camera / Model S1100XL	1989	1993	135	259.95
KODAK Stereo Camera	1954	1959	135	84.50
KODAK STAR Camera (premium-made in Brazil)	1985		110	*
KODAK STAR 235 Camera	1990	1994	135	44.95
KODAK STAR 335 Camera	1990	1994	135	49.95
KODAK STAR 435 Camera	1990	1994	135	49.95
KODAK STAR 535 Camera	1992	1995	135	74.95
KODAK STAR 635 Camera	1990	1991	135	79.95
KODAK STAR 735 Camera	1991	1994	135	74.95
KODAK STAR 735R Camera	1992	1994	135	87.95
KODAK STAR 835AF Camera	1991	1995	135	94.95
KODAK STAR 935 Camera	1991	1993	135	89.95
KODAK STAR 1035Z Camera	1993	1995	135	199.95
KODAK STAR 1035ZD Camera	1994	1995	135	219.95
KODAK STAR 275 Camera	1993	1995	135	41.95
KODAK STAR Auto Focus Camera	1995	1996	135	94.95
KODAK STAR Focus Free Camera	1995	1997	135	41.95
KODAK STAR Motordrive Camera	1995	1996	135	69.95
KODAK STAR Zoom 70 Camera	1995	1997	135	
KODAK STAR Zoom 105 Camera	1994	1995	135	295.95
KODAK STAR 110 Camera	1993		110	18.95
KODAK TOURIST Camera	1948	1951	620	95.00
KODAK TOURIST II Camera	1951	1958	620	100.00

CAMERA NAME	ON THE MARKET		FILM SIZE	ORIGINAL LIST PRICE
	FROM	TO		
KODAK VIGILANT Six-16 Camera	1939	1942	616	\$42.50
KODAK VIGILANT Six-20 Camera	1939	1949	620	38.00
KODAK VIGILANT Junior Six-16 Camera	1940	1948	616	12.50
KODAK VIGILANT Junior Six-20 Camera	1940	1948	620	11.00
KODAK Vollenda Camera	1932	1937	127	44.50
KODAK VOYAGER Camera	1989	1990	135	*
KODAK WINNER Camera	1988		110	11.95
WINNER POCKET Camera	1979	1990	110	*
KODAK World's Fair Flash Camera	1964	1966	127	7.95
No. 4 KODET Camera	1894	1897	plate or roll holder	20.00
No. 4 Folding KODET Junior Camera	1894	1897	plate or roll holder	10.00
No. 4 Folding KODET Camera	1894	1897	plate or roll holder	23.50
No. 4 Folding KODET Special Camera	1895	1897	plate or roll holder	33.00
No. 5 Folding KODET Camera	1895	1897	plate or roll holder	36.00
No. 5 Folding KODET Special Camera	1895	1897	plate or roll holder	48.00
New York World's Fair Baby BROWNIE Camera	1939	1940	127	1.25
New York World's Fair BULLET Camera	1939	1940	127	2.25
"C" Ordinary Glass Plate KODAK Camera	1892	1895	plates	15.00
"A" Ordinary KODAK Camera	1891	1895	darkroom loaded film	6.00
"B" Ordinary KODAK Camera	1891	1895	darkroom loaded film	10.00
"C" Ordinary KODAK Camera	1891	1895	darkroom loaded film	15.00
No. 1 PANORAM KODAK Camera	1900	1901	105	10.00
Model B	1901	1903	105	10.00
Model C	1903	1907	105	10.00
Model D (Patent date 6-16-14)	1907	1926	105	10.00
No. 3A PANORAM KODAK Camera (120°)	1926	1928	122	40.00
No. 4 PANORAM KODAK Camera (142°) (No lens cover)	1899	1900	103	20.00
Model B (lens cover, brilliant finder)	1900	1903	103	20.00
Model C	1903	1907	103	20.00
Model D	1907	1914	103	20.00
Model D (Patent date 6-16-14)	1914	1924	103	20.00
Pocket KODAK Camera	1895	1896	102 & plate	5.00
Model '96	1896	1897	102 & plate	5.00
Model '97	1897	1898	102 & plate	5.00
Model '98	1898	1899	102 & plate	5.00
Model '99	1899	1900	102 & plate	5.00
Model D	1900	1901	102 & plate	5.00
No. 1 Pocket KODAK Camera	1926	1932	120	17.00
No. 1 Pocket KODAK Camera (In 4 colors: blue, brown, gray, green)	1929	1931	120	18.00
No. 1A Pocket KODAK Camera	1926	1932	116	18.00
No. 1A Pocket KODAK Camera (In 4 colors: blue, brown, gray, green)	1929	1932	116	20.00
No. 2C Pocket KODAK Camera	1926	1932	130	21.00
No. 3A Pocket KODAK Camera	1927	1933	122	23.00

CAMERA NAME	ON THE MARKET		FILM SIZE	ORIGINAL LIST PRICE
	FROM	TO		
No. 1 Pocket KODAK Junior Camera (Black and 3 colors)	1929	1932	120	\$9.00
No. 1A Pocket KODAK Junior Camera (Black and 3 colors)	1929	1932	116	10.00
No. 1 Pocket KODAK Series II Camera	1922	1932	120	22.50
No. 1A Pocket KODAK Series II Camera	1923	1931	116	24.50
No. 1A Pocket KODAK Series II Camera (in 4 colors)	1928	1931	116	25.00
No. 1 Pocket KODAK Special Camera	1926	1934	120	55.00
No. 1A Pocket KODAK Special Camera	1926	1934	116	60.00
No. 2C Pocket KODAK Special Camera	1928	1933	130	70.00
No. 3 Pocket KODAK Special Camera	1926	1928	118	62.50
3B Quick Focus KODAK Camera (Models A, B, C)	1906	1911	125	12.00
No. 4 Screen Focus KODAK Camera	1904	1910	123	87.50
Six-16 KODAK Camera	1932	1936	616	40.00
Six-20 KODAK Camera	1932	1937	620	38.00
Six-Three KODAK No. 1A Camera	1913	1915	116	38.00
Six-Three KODAK No. 3 Camera	1913	1915	118	40.00
Six-Three KODAK No. 3A Camera	1913	1915	122	50.00
"C" Special Glass Plate KODAK Camera	1891	1895	plates	25.00
No. 1A Special KODAK Camera	1912	1914	116	63.00
No. 3 Special KODAK Camera	1911	1914	118	65.00
No. 3A Special KODAK Camera	1910	1914	122	80.50
No. 1A Speed KODAK Camera	1909	1913	116	78.50
No. 4A Speed KODAK Camera	1908	1913	126	112.50
Stereo KODAK, Model 1 Camera (Folding)	1917	1925	101	53.00
No. 2 Stereo KODAK Camera	1901	1905	101	15.00
Super KODAK Six-20 Camera	1938	1944	620	225.00
Vanity KODAK Camera (V.P. Series III in: blue, brown, gray, green, and red)	1928	1933	127	30.00 w/ matching case
Vanity KODAK Ensemble Vanity KODAK Camera, Model B, w/lipstick, compact, mirror change pocket, 3 colors: beige, gray, and green (Cosmetics by Richard Hudnut)	1928	1929	127	20.00
Vest Pocket AUTOGRAPHIC KODAK Camera ("Japan crystal" crackle finish starts in 1920)	1915	1926	127	10.00
Vest Pocket AUTOGRAPHIC KODAK Special Camera	1915	1926	127	22.50
Vest Pocket KODAK Camera	1912	1914	127	12.00
Vest Pocket KODAK, Model B Camera (AUTOGRAPHIC)	1925	1934	127	7.50
Vest Pocket KODAK Series III Camera (AUTOGRAPHIC)	1926	1934	127	18.00
Vest Pocket KODAK Special Camera	1912	1935	127	25.00
KODAK VR 35 Camera, Model K10	1986	1988	135	130.00
KODAK VR 35 Camera, Model K12	1986	1989	135	200.00
KODAK MEDALIST VR 35 Camera, Model K14 (Special edition camera with date back)	1986	1989	135	239.95
KODAK VR 35 Camera, Model K40	1986	1993	135	83.00
KODAK VR 35 Camera, Model K60	1986	1988	135	93.00
KODAK VR 35 Camera, Model K80	1987	1993	135	130.00
KODAK VR 35 Camera, Model K300	1987	1990	135	*
KODAK VR 35 Camera, Model K400	1987	1990	135	*
KODAK VR 35 Camera, Model K500	1987	1990	135	*

\* For promotion or premium use by other companies—not available in retail stores.

† Specialty photo dealer only.

‡ Used as a premium camera, 1984–1997.



# History of KODAK Cameras

---

Consumer Imaging  
EASTMAN KODAK COMPANY • ROCHESTER, NY 14650

